

- 1) DECK LID PROTECTOR COMES FOLDED UP AND SHOULD BE LAID OUT TO RELAX
- 2) LIGHTLY RUB SOFT CLOTH OVER PROTECTOR TO GENERATE STAIC CLING
- 3) THE PROTECTOR IS CUT TO LAY NATURALLY IN THE FORM OF THE CONV. TOP GASKET. IT'S CUT IN 2 HALVES FOR EASIER APPLICATION. START APPLICATION IN THE CENTER OR OUTSIDE...IT MAY TAKE A COUPLE OF TRIES BEFORE YOU GET IT PERFECT. YOU CAN ALSO APPLY USING A SPRITZ OF WATER ON SURFACE TO MAKE IT EASIER TO GET EXACTLY IN PLACE THEN DRY WITH A CLEAN RAG TO GENERATE STATIC.
- 4) IT'S A GOOD IDEA TO REMOVE PROTECTOR WHEN DRIVING WITH TOP DOWN
- 5) DO NOT USE ON UNCURED PAINT...WAIT AT LEAST 30 DAYS AFTER PAINTING!