

# ULTIMATE ANSWER KIT

To insert the Ultimate Answer Kit without removing the brakes, rock the pad up and down while still inside the caliper, sliding (forcing) the sleeve down along the trailing edge of each pad as far as possible.

Trim off excess.

## NOTE:

If noise persists, move sleeve from rear edge to front edge. Or, place a sleeve on both

