

# HOOD ACCENT DECAL DIRECTIONS

- 1) THE MOST IMPORTANT THING HERE IS THAT YOU GET THE AREA WHERE DECAL GOES VERY CLEAN! EVERY LITTLE PIECE OF TRASH WILL SHOW UNDER DECAL.
- 2) MIX A SPRAY BOTTLE WITH WATER AND A FEW DROPS OF LIQUID SOAP. DON'T OVER DO THE SOAP, YOU JUST WANT TO BE ABLE TO SLIDE DECAL AROUND.
- 3) DECIDE WHICH SIDE EACH DECAL GOES ON.
- 4) SPRAY THE AREA WITH A LOT OF SOLUTION, YOU CAN'T GET TOO MUCH.
- 5) PEEL THE APPLICATION TAPE FROM THE BACKING PAPER. THE DECAL SHOULD COME OFF WITH THE APPLICATION TAPE.
- 6) SPRAY THE SIDE OF THE DECAL GOING AGAINST THE CAR.
- 7) LAY DECAL IN THE AREA IT GOES. SLIDE IT AROUND TILL IT IS CENTERED WHERE YOU WANT IT.  
THEN SPRAY THE APPLICATION TAPE SO SQUEEGEE WILL SLIDE ACROSS DECAL.
- 8) USE A PADDLE OR ROLLER TO PUSH WATER AND AIR BUBBLES FROM UNDER DECAL.  
I'M NOT SURE I CAN SAY THIS ENOUGH...DON'T GET IN A HURRY....  
NOW...LET IT DRY WHILE YOU DO THE OTHER SIDE.
- 9) AFTER YOU'VE ALLOWED DECAL TO DRY COME BACK AND PULL APPLICATION PAPER FROM TOP OF DECAL. DON'T PULL UP..SLOWLY PULL IN THE DIRECTION OF DECAL KEEPING CLOSE TO THE HOOD.  
TAKE YOUR TIME....DON'T GET IN A HURRY!!