

Part# 3938 - 1968-1982 Headlight assembly parts kit / packing list

This kit does one headlight assembly / 2 kits needed per car

- ❑ 1- 3845k Adjuster Kit (4 plastic adj, 4 long adj bolts, 2 springs, 10 machine screws)
- ❑ 2- 362995 Bearing assembly
- ❑ 1- 3/4" Link bolt (large stepped hex bolt)
- ❑ 1- 3915898L Link bolt bushing (for large hex bolt)
- ❑ 15- 5/16" Washers (general assembly)
- ❑ 2- 1/4" x 1/2" Bolts for stop
- ❑ 2- 1/4" Washers for stop
- ❑ 3- 1/16" x 3/4" cotter pins
- ❑ 4- 5/16" x 18 nuts (vac can mount)
- ❑ 2- 3922497 Kidney bean bushings
- ❑ 1- Hdlt bezel screw kit (2 short for front, 2 long for side, 2 J-clips for side)
- ❑ 2- 5/16"x 3/4" -18 bolts (for brace rods)
- ❑ 9- 5/16" x 1/2" -18 bolts (for w bracket, and 362995 bearing ass.)
- ❑ 2- 3926434 (narrow spring)
- ❑ 2- 3935516 (fat spring)
- ❑ 3- 3/8" washers (to be used by cotter pins on link pins)
- ❑ 2- 3845cl Stop collars
- ❑ 1- 395034 Front hshg link
- ❑ 1- 395887 Clevis
- ❑ 1- 3922498 Clevis bushing
- ❑ 1- 3926433 Link pin, long (hshg actr link)
- ❑ 1- 3927672 Link pin (hshg actr rear link)
- ❑ 1- 3927676 Link pin, non machined (for alum link to w bracket #461162)
- ❑ 2- 3915898 Bushing (one for above#3927676, and one to be cut for #3927674 link pin)

*Include this packing list for customer