
C4 Corvette Emergency Hood Release Cable Instructions

STEP 1. Open hood, remove cables from packaging.

STEP 2. Secure cable with supplied wire tie to the factory hood cable to keep it in place.

STEP 3. Trim excess wire tie, loop cable end over the stock cable end fitting. Feed the large looped end under the hood where you can access it in case of an emergency.