

#1092KIT

INSTALLATION INSTRUCTIONS/TIPS

1963-67 Corvette

THE FOLLOWING ITEMS ARE INCLUDED

- | | |
|--|--|
| <input checked="" type="checkbox"/> 60" Matching wireon | <input checked="" type="checkbox"/> Finished Header Strip |
| <input checked="" type="checkbox"/> 2 Flanged Wireon Tips | <input checked="" type="checkbox"/> 1092 Pads with 2" Quarters |
| <input checked="" type="checkbox"/> 2 Wireon Screws | |
| <input checked="" type="checkbox"/> 2 Tabs with snaps | |
| <input checked="" type="checkbox"/> 3/16" Plastic 78" | |

THIS ORDER HAS BEEN CAREFULLY INSPECTED BY mor DATE 11-12-25
FOR ANY HOLES, CUTS OR OTHER DEFECTS INCLUDING FINISH

BOW HEIGHT 18 1/2"

CAUTION MUST READ BEFORE STARTING INSTALLATION

WE RECOMMEND CONVERTIBLE TOPS/WINDOWS BE INSTALLED BY AUTOMOTIVE TRIM/UPHOLSTERY SHOPS
TOP/WINDOW IS NOT GUARANTEED AGAINST IMPROPER INSTALLATION OR FRAME PROBLEMS.
ALWAYS USE STAINLESS STEEL STAPLES TO AVOID RUST

MARKED TACK LINE IN TOP/WINDOW STARTS IN THE CENTER OF TACK RAIL

REMOVE TOP

01. Unfold top, inspect, and make sure you have the right top for your car, including color & material.
02. Dry fit top by placing it over existing top making sure everything is correct, including **top # marked on front of top in center and on each quarter before removing old top.**
03. If you suspect you received the wrong item contact supplier immediately. We will accept it back for credit & ship correct item provided incorrect item is in sellable condition.
04. **NO CREDIT will be issued after installation has been started or item damaged/scratched.**
05. Place a blanket or heavy cloth on rear section of car to prevent scratching.
06. Remove all weather strips except on the sides of the center deck.
07. Detach top from frame by removing wireon & staples from rear bow; Remove 3/16 cord from around rear rail, and release top from front bow.
08. Finish removing old top from car (**save old top for reference until job is complete**).

INSTALLATION

01. **Attach the glue flaps at side window to help center top then attach material around rear rail then attach to rear bow then center deck to rear bow.**
02. Pull top forward over edge of front bow and draw pencil line across the edge. Unlatch front & rear and pull material about 1/4" past line and attach to front bow.
03. Latch the front and rear to see if any adjustments need to be made. Reinstall front and side weather stripping.
04. Glue side & vertical glue flaps and attach side and rear weather stripping.
05. Any wrinkles where top was folded should come out with sunshine, light heat or steam.
06. Wash top and car. *ENJOY YOUR CONVERTIBLE*

KEE AUTOTOP MANUFACTURING CO.

TECH SUPPORT 1-800-438-5934

ALL RIGHTS RESERVED, REPRINTING OF ANY PORTION OF THIS INSTRUCTION SHEET IS PROHIBITED WITHOUT THE EXPRESS PERMISSION OF KEE AUTO TOP MANUFACTURING CO., CHARLOTTE, NC