



Thank you for your support and love and I appreciate you very much for supporting me and my little hobby of making C3 Corvettes a little cool again! I hope you enjoy these C3 lights and may they bring you happiness!

- To install taillight, please connect connector with plug to 2 taillights and piggy back the other taillights to them on each side of the car
- Please make sure to piggy back inner taillights to outer taillights so they all work together as the C3 did not come like that from factory
 - RED WIRE --> BRAKE/TURN SIGNALS
 - BLACK WIRE--> RUNNING LIGHT
 - WHITE WIRE--> GROUND
 - Just make sure you match the wires up when you are piggy backing them on each side

- So when done, you should have a taillight that is on the outer side of the car on each side that is connected to the OEM connect point on the taillight harness of the car (make sure it sits and twists to lock otherwise you did not install it correctly) and a taillight that is piggy back to it on each side of the car.
- If you don't know how to take off your stock tails, please watch a video on how to. There are plenty available.
- Included is a flasher as well as you are now rocking LED tails.
 - If you are not sure of how to install the flasher, there are many videos on YouTube showing how to install it!
- If you have any trouble, reach out to me via Instagram @RETROVETTE
- These lights are for **Off-road use only**, it is not my responsibility for whatever happens as all states have different laws when it comes to the modifications of taillights! The lights have all proper functionality: turn signals, brake, running light.
- **WARRANTY INFORMATION:**
 - The lights come with a 30-day warranty! Any trouble after the 30-day period, please let me know and if it is something I can fix, I wouldn't mind helping, but if it is user fault, something breaks or anything that is caused by the user, a fee will be applied to the repair of the lights.