

#20-461

Front Door U channel Clip Installation 2 & 4 Dr Sdn/Wgn/Sdn Delivery

1. High side of clip goes toward inside of car, so when you are finished you will have a channel for the right door and 1 for the left. Use old U channel as a guide to locate clips.
2. Once you have marked the channel for clip location, install clips 1 at a time by placing clip, teeth up on a flat surface. Place U channel, open side up, on top of clip and press down by hand to begin to engage teeth in channel.
3. Use a wooden block [1/2" thick, 1 or 2" wide & long enough for you to hold say 6 to 8"] Place block into channel over clip & tap block down to firmly seat channel in the clip [the teeth will go thru the channel & penetrate the block].
4. Remove block when clip is seated, then use a 1/4" flat punch to tap teeth over to lock clip onto channel, be carefull to locate each tooth before you start hammering. Use punch 1st on an angle near as possible to tip of tooth to tap tooth over; then a couple of light hits is all that is necessary to fully bend the teeth flat. Bend teeth to outside.
5. It is good insurance to place a drop or 2 of a fast setting glue on each clip before you install them.