




# HA04E

**Heater Box Seal Kit  
1968-77 (With A/C)**



## Installation Instructions

1. Disassemble all duct and box components.
2. Thoroughly remove and clean location of original seals.
3. Determine the location of new seals and gaskets.
4. Use a weatherstrip adhesive to install new seals