

DRIVER SIDE  
FRONT PARKING LIGHT  
BEZEL/HOUSING \*



FORWARD LAMP  
HARNES CONNECTION

PASSENGER SIDE  
FRONT PARKING LIGHT  
BEZEL/HOUSING \*



FORWARD LAMP  
HARNES CONNECTION

- \* The original front parking/turn signal light assembly was comprised of a bezel/housing with a non-removable light socket and wiring.
1. To install this repair set, customer must decide best method to separate the old light socket from its bezel/housing.
  2. After removing the old socket, insert the new socket into the opening of the bezel/housing. The "fingers" on the lamp socket will temporarily hold it in place for the next step.
  3. After the new light socket had been affixed to bezel/housing, we recommend the use of a permanent epoxy (or similar product) applied onto both the socket and bezel/housing. You ultimately want to make sure that the socket will not detach from the bezel/housing, and that the connection is water-tight. If you do not perform this step, the socket will probably separate from the bezel/housing.

Part #: **VPL6366**  
Instruction Sheet #: **INS8609**

REV. 12/15  
8.5x5.5

Copyright 2015, Leclair Limited Inc. Information and illustrations on this sheet are the property of Leclair Limited Inc. No part of this sheet may be reproduced without licensing approval from Leclair Limited, Inc.